



Keylite Blinds

Solar Blind Installation



Components


Check all the components have been supplied



Screws (x6)

Remote control

Installation Brackets (x2)



Cassette (x1)

Tools Required

Check out our installation video on the Keylite website.

www.youtube.com/watch?v=itUOxlfmdJo



WARNING

DO NOT OPERATE REMOTE CONTROL UNTIL THE BLIND HAS BEEN FULLY INSTALLED.





Instructions










Keylite.


























Blind Operation

SCREEN

UP


STOP

DOWN

PAIRING THE REMOTE

When using a multichannel remote the channel number the user wishes to use must be selected first on the remote before pairing.

Open the blind cassette by pressing the 2 buttons on either end of the cassette to release and rotate forward. IMPORTANT after pairing your remote control please ensure blind cassette is fully closed.



OPERATION

<

keylit<u>e</u>

Close the blind: press and hold the down button on the remote control for 1 second then release the blind will begin to close, the blind will stop automatically at the bottom of the window.

Open the blind: press and hold the up button on the remote control for 1 second then release the blind will begin to open, the blind will stop automatically at the top of the window.

The blind can be stopped at any point during an open or close cycle by pressing the stop button for 1 second then releasing. To operate multiple blinds simultaneously select channel 0 on the remote control.



01283 200 197 UK Tel: 028 8676 7515 NI Tel: **ROI Tel:** 048 8676 7515

Sales@keyliteblinds.com